


ASSEMBLY INSTRUCTIONS


This instruction applies to the following items:

W2430-W3630、W2436-W3636


Step 1




Step 2




Step 3



Step 4



Step 5



Description	Description
Φ 3.5*12 SCREW	FOR SCREWING CLEAT AND BUCKLE
Φ 3.5*16 SCREW	FOR SCREWING HINGE AND DOOR
Φ 3.5*19 SCREW	FOR SCREWING HINGE AND FRAME, AND CORNER BLOCK
Φ 3.5*25 SCREW	FOR SCREWING SIDE PANEL/BACK PANEL
Φ 3.5*30 SCREW	FOR SCREWING THE SIDE PANEL/BACK PANEL TO THE TOP/BOTTOM PANEL