
ASSEMBLY INSTRUCTIONS

This instruction applies to the following items:

W3012-W3024、W3612-W3624、W362124 W301224、W361224、W361524、W361824



∮3.5*30 SCREW FOR SCREWING THE SIDE PANEL/BACK PANEL TO THE TOP/BOTTOM PANEL