

## **ASSEMBLY INSTRUCTIONS**


This instruction applies to the following items:


WP2484、WP2490、WP2496


WP3084、WP3090、WP3096











Description	Description
∮ 3.5*12 SCREW	FOR SCREWING CLEAT AND BUCKLE
∮ 3.5*16 SCREW	FOR SCREWING HINGE AND DOOR
∮ 3.5*19 SCREW	FOR SCREWING HINGE AND FRAME, AND CORNER BLOCK
∮ 3.5*25 SCREW	FOR SCREWING SIDE PANEL/BACK PANEL
∮ 3.5*30 SCREW	FOR SCREWING THE SIDE PANEL/BACK PANEL TO THE TOP/BOTTOM PANEL